



**** MUST READ INSTALLATION GUIDE BEFORE USING! ****

1. Make sure joints are free from debris and all ponded water removed. **Paving surface and joints must be pre-soaked and kept wet until the jointing process has been completed.** DO NOT LEAVE POOLED WATER IN JOINTS
2. 1 x 25kg bag requires 4.25 litres of water. **Use measuring jug** as guide. Mix in 20lt bucket for 3-5 minutes until smooth & lump free.
3. **Apply to surface without delay**, spread and push into joints using a rubber squeegee. **DO NOT store grout in bucket!** Repeatedly top up joints where grout may have slumped. Use squeegee to remove as much grout off surface as possible.
4. **SURFACE MUST BE KEPT MOIST AT ALL TIMES** using soft mist spray.
5. When grout has hardened sufficiently the paving surface must be cleaned using a hose and broom. **Use high pressure with caution** as this will blow grout from joints. Cleaning must be carried out thoroughly and **no grout must be allowed to remain on surface of paving.**

PRECAUTIONS:

- Joints **MUST** be free from ponding water!
- **MUST USE MEASURING JUG – 4.25 Litres Water Per Bag.**
- **Mix only enough material to apply in 4 minutes. DO NOT MIX MORE THAN CAN BE WASHED OFF IN TIME FROM GROUT SETTING. TRY ONE BAG FIRST.**
- Wash all tools frequently.
- **KEEP SURFACE MOIST AT ALL TIMES! Fine Mist Spray Only.**
- **NEVER remix or add extra water!**
- **Wear protective clothing. Avoid skin and eye contact.**
- **Cool temperatures retard, warm temperatures accelerate.**

Standard Smooth Curing Times Rule Of Thumb:

15min @20°C.:

at 10°C it takes twice as long as it does at 20°C.

at 5°C it takes four times as long as it does at 20°C.

at 25°C it takes half as long as it does at 20°C.

at 30°C it is 4 times quicker than at 20°C.

**** Essential Equipment!! ****

- **Long handle squeegee**
- **Hose with good adjustable spray gun or nozzle, for Mist Spray and Firm Spray requirements**
- **5lt Measuring Jug**
- **20lt Bucket**
- **Drill with mixing paddle**
- **Soft Broom and Stiff Broom**
- **Rubber Grouting Trowel**
- **Cloth tape if required for masking off areas and edges without haunch**